




POA-6600



RESISTANCE

EU	100/0.004	1000/0.004	10000/0.004
EU	100/0.004	1000/0.004	10000/0.004
E2	200/0.004	2000/0.004	20000/0.004

RESISTANCE

EU	100/0.004	1000/0.004	10000/0.004
EU	100/0.004	1000/0.004	10000/0.004
E2	200/0.004	2000/0.004	20000/0.004

POWER TRANS.

EU	100/0.004	1000/0.004	10000/0.004
EU	100/0.004	1000/0.004	10000/0.004
E2	200/0.004	2000/0.004	20000/0.004

NOTE: Means important safety item, which must be replaced, when necessary, by a part specified or meeting the specification by the manufacturer.